

9. TECHNICAL INFORMATION

- Power consumption (OFF mode): 0.1W
- Period after which the equipment reaches automatically OFF mode: 0 minute

DISPOSAL

This product must not be disposed of with household waste.

Please return it to an appropriate collection point for recycling in accordance with local regulations.

Morsø Jernstøberi A/S
Furvej 6, DK-7900 Nykøbing Mors

www.morsoe.com
info@morsoe.com


morsø
DANISH DESIGN SINCE 1853



Subject to corrections and printing errors. 2026 // 72994341 // UK

Keep your purchase receipt, as it will be needed in case of warranty claims.

www.morsoe.com



USER MANUAL - UK



Striato Electric Kettle
Model: WK8553AEEK

220-240V ~ 50/60Hz, 1850-2200W

PLEASE READ AND RETAIN THESE INSTRUCTIONS

Designed for everyday use, this kettle combines functionality with a calm and considered design.

To ensure safe and optimal performance, please read these instructions carefully before use.

1. SAFETY AND USE

- Read all instructions before using the appliance.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- The appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- If the power cord is damaged, it must be replaced by qualified personnel.
- This appliance is intended for heating water only.
- Failure to comply with the instructions for use may make the item unsuitable for use in contact with food.
- This product is specifically designed to heat water to the boiling point (100 °C).

This appliance is intended for everyday use in:

- Private homes
- Staff kitchens and working environments
- Hotels, motels and similar residential settings
- Bed and breakfast environments
- Do not overfill the kettle, as boiling water may be ejected.
- Always use the kettle with the supplied base.
- Ensure the kettle is switched off before removing it from the base.
- Do not operate the appliance if it is damaged or malfunctioning.
- Do not immerse the kettle, base, cord or plug in water or other liquids.
- Avoid spilling water onto the contact area between the kettle and the base.
- Always place the appliance on a stable, dry and level surface.
- Do not use outdoors.
- Disconnect the appliance from the power supply when not in use and before cleaning.
- Surfaces may become hot during use – handle with care and allow the appliance to cool before touching.



IMPORTANT

Only use this appliance as described in this manual. Incorrect use may result in injury or damage to the appliance.

- Never operate the kettle without water.
- Do not move the kettle while it is boiling.
- Do not open the lid while boiling or when steam is present.
- Ensure sufficient space around the appliance for proper air circulation.

2. DESCRIPTION OF PARTS

- 1.5 l kettle
- Stainless steel Inner tank
- Led backlit control knob
- Electric base

3. PERFORMANCE

- Variable temperature from 60°-100°
- Anti-drip spout
- Digital temperature sensor
- Fully removable lid and filter for easy cleaning
- Dry-boil protection
- Rated power 1850-2200W

4. OPERATION

Before First Use

- Remove all packaging materials and protective covers.
- Clean all parts that come into contact with food.
- Ensure that the power cord is not damaged before use.
- Ensure voltage compatibility

Before first use, operate the kettle 2–3 times with fresh water, following the instructions below.

This process removes any residual substances from the manufacturing process.

USING THE KETTLE

Filling the Kettle

- Remove the kettle from the base.
- Remove the lid and fill with water between the minimum (0.5 l) and maximum (1.5 l) levels.
- Close the lid securely.

Starting the Kettle

- Place the kettle on the base and connect to the power supply.
- Select the desired temperature using the control knob.
- Press the control knob to start heating.

The indicator light will illuminate during operation. The kettle will switch off automatically once the selected temperature is reached.

To stop the process manually, press the control knob again.

Standby Mode

When connected to the power supply, the indicator lights will briefly illuminate before switching off. The appliance then enters standby mode.

Temperature Control

- If a different temperature is selected during heating, the kettle will adjust and stop at the new setting.
- If the water temperature already exceeds the selected level, the kettle will not start heating.

Boil-Dry Protection

The kettle is equipped with a safety cut-out that automatically switches off the appliance if it is operated without water.

If activated:

- Disconnect the kettle from the power supply
- Allow it to cool for approximately 15 minutes
- Refill with water before use

Pouring Water

Remove the kettle from the base and pour carefully from the spout.

5. PROCESSING GUIDE

Refer to the recommended operating times in this manual.

Do not exceed maximum capacities or processing times.

6. CARE AND CLEANING

Exterior

- Always disconnect the appliance and allow it to cool before cleaning.
- Empty the kettle after use.
- Clean the exterior with a soft, damp cloth and dry thoroughly.
- Do not use abrasive cleaning agents or scrub sponges on the non-metal parts, as it may scratch the surface.
- Do not immerse the kettle or base in water.
- Do not use sharp utensils

Filter

- Remove the filter once the kettle has cooled.
- Rinse under warm water and remove any residue. The filter can be immersed in diluted descaling agent to remove build up limescale.
- Reinsert after cleaning.

Descaling

Regular descaling ensures optimal performance:

- Fill the kettle halfway with water and add the appropriate descaling agent to the water
- Boil the mixture and let it stand for 15 minutes.
- Repeat the process once more.
- Rinse thoroughly with clean water.

7. STORAGE

Store the appliance in a cool, dry and well-ventilated place.

Ensure the appliance is unplugged and completely dry before storage.

8. SERVICE AND SAFETY

- Servicing must be carried out by authorised personnel only.
- Do not operate continuously for extended periods.
- Inspect your kettle regularly. If there are any signs of larger internal (or external) damage to the product, such as cracks, tearing, corrosion or other potential defects, please refrain from using it any further. Contact the location where you have bought the product to evaluate whether it is still safe to use.