



# Morsø P50/51

**Before you start using your new Morsø pellet stove, make sure that the stove has been installed according to the local regulations.**

**The installation must be approved by an authorized chimney sweeper.**

## Quick start guide

1. Place the supplied baffle in the stove (see backside)
2. Before initial ignition, fill up the pellet storage magazine including a handful of pellets in the fire pot - Only use 6 mm pellets.
3. Switch on the stove, pressing button No.3 until the display shows start. The stove will automatically ignite. Wait until the stove, after approx. 10 min., switch to running mode.
4. Set temperature pressing button 4 and adjust with button 1 and 2.
5. Set power pressing button 5 and adjust with button 1 and 2.

**IMPORTANT – newer set the power level higher than necessary, to reach the wanted temperature. That will result in unnecessary noise from the stove.**

**NB. - If the connection between the stove and the remote control is not established automatically, do the following.**

1. Turn off the power on the main switch.
2. Press button 1 and 2 at the same time, the display shows "select unit"
3. Select unit 0
4. Turn on the power on the main switch.
5. Press the RED button until you hear a BIP tone.

### You have now started:

**Then you have both the time and the warmth to read the manual carefully.**

**It is very important to learn all the different functions of the stove including the safety precautions.**

# Mounting off the Baffle

